

## SABRE YACHTS

### WATER TANK VENT INSTALLATION INSTRUCTIONS

1. Six inches forward of the water tank, cut out a 2" long section of the water fill hose. Install the  $1\frac{1}{4}$ " x  $1\frac{1}{4}$ " x  $\frac{1}{2}$ " plastic tee using  $1\frac{1}{4}$ " hose clamps.
2. Centered 2" below the vinyl rub rail and 2" forward of the water deck fill pipe, drill a  $\frac{3}{4}$ " hole and install the 90° vent fitting.
3. Connect  $\frac{1}{2}$ " clear hose at vent and tee using  $\frac{1}{2}$ " hose clamps.
4. Secure clear vent hose to underside of V berth using plastic hose strap.
5. There should be no sag in the vent line.
6. Use silicone sealant at all hose connections.

#### The Vent Kit includes:

- 1 - 90° vent fitting
- 1 -  $1\frac{1}{4}$ " x  $\frac{1}{2}$ " plastic tee
- 2 -  $1\frac{1}{4}$ " st. st. hose clamps
- 2 -  $\frac{1}{2}$ " st. st. hose clamps
- 60" -  $\frac{1}{2}$ " x  $\frac{1}{8}$ " wall clear tube

